

# SPRAY GUN PAINT REMOVER

## TECHNICAL DATA SHEET



---

Stock	Product	Colour	Size
SSGC / 10065	Spray Gun Paint Remover	Clear	510g Aerosol

### DESCRIPTION:

**Spray Gun Paint Remover** keeps paint guns running at top performance by allowing immediate and effective cleaning after each use. It is designed to flush away fresh paint from the fluid passages. The powerful blasting action creates turbulence behind the fluid nozzle, thoroughly cleaning and flushing out any remaining paint residue.

### FEATURES:

- Saves time, labor and material.
- Unique nozzle designed to work with disposable cup adapters.
- Quickly dissolves paint.
- Pinpoint spray.

### DIRECTIONS:

1. Hold can in an upright position and aim away from body.
2. Liberally spray outside surface area of paint gun and wipe clean with paper towel.
3. For removing paint in fluid passages, pull the paint gun trigger and spray Paint Remover directly into cup or paint inlet. Use a continuous spray until waste runs clear.
4. For PPS type adapters, remove the cup from the adapter and place grommet firmly against adapter. Pointing into a waste container, pull the trigger on the paint gun and push down on the Spray Gun Paint Remover Nozzle, flushing internal passages clean. Release the nozzle on the aerosol to stop spraying, then release trigger on paint gun. Wipe gun clean.

### PERSONAL PROTECTION:

Wear protective eyewear. Be careful not to get solvent into eyes while using. Keep out of reach of children. All users should review the Safety Data Sheet (SDS) prior to use for possible health hazards. Copies of the SDS sheet are available upon request.